

12" Air Dancer® Blower



I. Assembly and Operation

1. Plug the power cord into a standard household electrical outlet.
2. Attach the Velcro base of your 12" diameter Air Dancer® onto the matching Velcro outer rim of the blower.
3. Turn the blower on switch and watch your Air Dancer® in action.

II. Specs

- Number of Speeds: 1
- Blower Horsepower: 1/3hp
- Power: 115v/60hz
- CFM: 2,100
- Amps: 5.8
- All parts needed for operation are included
- Diameter of blower is 12"
- Compatible with all velcro mount dancing man attachments of similar diameter
- Proprietary design and functionality.
- Approx Shipping Dims: 15" x 15" x 15" - (23 lbs)

II. To Reorder, please call LookOurWay at 866-586-3888.