

18" Air Dancer® Weather Resistant Blower



I. Assembly and Operation

1. Install the included wheels with nut on each of the lower four corners of the blower as pictured above. This will allow an opening space for a sufficient amount of air to flow into the blower to power your Air Dancer®.
2. Plug the power cord into a standard household electrical outlet.
3. Attach the Velcro base of your 18" diameter Air Dancer® onto the matching Velcro outer rim of the blower.
4. Turn the dial switch of the blower to your preferred speed and watch your Air Dancer® in action.

II. Specs

- Number of Speeds: 3
- Blower Horsepower: 1hp
- Power: 110v/60hz
- CFM: 5,000
- Amps: 11
- All parts needed for operation are included
- Diameter of blower is 18"
- Compatible with all 18" velcro mount dancing man attachments
- Locking Roller Wheels: Yes
- US patent (# 6,186,857) for the Air Dancer® Technology, is strictly enforced.
- 1 Year Limited Warranty

III. To Reorder, please call LookOurWay at 866-586-3888.