

# 9" Air Dancer® Blower



## I. Assembly and Operation

1. Plug the power cord into a standard household electrical outlet.
2. Attach the Velcro base of your 9" diameter Air Dancer® onto the matching Velcro outer rim of the blower.
3. Turn the blower on switch and watch your Air Dancer® in action.

## II. Specs

- Number of Speeds: 1
- Blower Horsepower: 1/4hp
- Power: 115v/60hz
- Amps: 1.67
- All parts needed for operation are included
- Diameter of blower is 9"
- Compatible with all velcro mount Air Dancer® attachments of similar diameter
- Proprietary design and functionality.
- Approx Shipping Dims: 11" x 11" x 14" - (10 lbs)

II. To Reorder, please call LookOurWay at 866-586-3888.